






7178.0435

Onderdelen informatie
Erzatzteil information
Spare part information
Information de pièces







POS:	Art.No.:	Omschrijving:	Aantal:
1	9289.0280	Cast Iron Chimney	2
2		Worktop	1
3		Oven	1
4		Back Panel	1
5		Side Panel Right	1
6	9289.0740	Electrical Terminal	1
7		Front Support	1
8		Cable Gland	1
9		Cable Fixing Part	1
10	9289.0405	Adjustable Legs	4
11		Legs Fixing Part	2
12		Nether Panel	1
13		Front Panel Fixing Part	1
14	9289.0630	Positions Switch	1
15	9289.0340	Thermostat	5
16		Door Outer Part	1
17	9289.0450	Door Handle	1
18		Door Inner Part	1
19	9289.0650	Knob	6
20		Front Panel	1
21	9289.0845	Positions Switch	1
22		Elc. Instalation Fixing Part	1
23	9289.0850	Oven Grate	1
24		Oven Grate Sliders	2
25	9289.0455	Heaters	6
26		Plate Heaters Fixing Part	4
27	9289.0040	Plate Heaters	2
27	9289.0305	Plate Heaters	2