



Spare part information


7178.3020



CombiSteel

7178.3020







Spare part list 7178.3020

POS:	Art.No.:	Omschrijving:	Aantal:
1	CS9289.0280	Iron Cast Chimney	2
2	**	Top Grate of Cooker	4
3	CS9289.0715	Burner	4
4	CS9289.1330	Thermocouple 80 cm	4
5	CS9289.0720	HT Pilot	4
6A	CS9289.0355	M8 Ø 1.60mm Inj LPG	4
6B	CS9289.0325	M8 Ø 2.20mm Inj NG	4
7	CS9289.1035	L Injector Fitting Part	4
8	**	Burner Fixed Part	1
9	CS7178.9065	GN 2/1 Oven Grate	1
10	CS9289.0135	Green Light Indicator	1
11	CS9289.0050	Red Light Indicator	1
12	CS9289.0465	Commutator Switch	1
13	CS9289.0460	300°C Thermostat	1
14A	CS9289.0650	Ø6 Knob	1
14B	CS9289.0906	Oven Up-Down Knob Bottom	1
15A	CS9289.0650	Ø6 Knob	1
15B	CS9289.0904	50-300°C Knob Bottom	1
16	CS9925.0018	0-1 Switch 3N	1
17	CS9289.0685	5x3 Electrical Terminal	1
18	**	Fiber Elc. Terminal Pad	1
19	**	Right Side Panel	1
20	**	PG 21 Cable Gland	1
21	**	Installation Part	1
22	CS9289.0405	Adjustable Legs	4
23	**	Grounding Terminal	1
24	**	2/1 Elc. Oven Block	1
25	**	Legs Fixing Part	2
26	**	Door Side Panel	1
27	**	Front Bottom Panel	1
28	**	1 Module Oven Door	1
29	CS9289.0075	S21 Gas Valve	4
30	**	1 Module Oven Gasket	1
31	CS9289.0445	Soft Hinge	2
32	**	Front Panel	1
33	**	Left Side Panel	1
34	**	Gas Tank	1
35	**	Back Panel	1
36	**	Front Side Panel	1
37	**	Oven Bottom Plate Left	1



Spare part list 7178.3020

POS:	Art.No.:	Omschrijving:	Aantal:
38	CS9289.0455	Oven Resistance 1,5kW	6
39	**	Oven Bottom Plate Right	1
40	**	Top Table	1
41	**	Oil Collector Sheet	2
.		## = Parts cannot be ordered separately.	
.		** = No article number known, must be requested specifically.	



7178.3020

Combisteel BV

Lichtschip 63
3991CP Houten
The Netherlands

+31 (0)30 285 00 90
info@combisteel.com
www.combisteel.com