




**7482.0025**

Onderdelen informatie  
Erzatzteil information  
Spare part information  
Information de pièces







POS:	Art.No.:	Omschrijving:	Aantal:
1/A		Door Handle	
1/B		Small lateral door handles	
2/A	9094.0380	Door supporting plate (right)	
2/B		Door supporting plate (left)	
3		Washer	
4		Door	
5	9094.0370	Door Glass	
6	9094.0375	Door glass gasket	
7		Counterdoor	
8		Door Frame	
9	9338.1266	Plate fixing screws	
10		Frontage	
11/A		Control panel frame	
11/B		Control panel label	
12		Insulating material	
13		Left covering panel	
14		Top covering panel	
15		Back covering panel	
16		Right covering panel	
17		Bottom covering pannel	
18		Jacket	
19		Cooking chamber	
20		Chimney	
24		Heating elements supporting frame	
25	9095.1505	Lamp holder	
26	9998.0444	Lamp glass	
27	9392.7350	Lamp	
29		Circuit brakers board	
30	9094.0290	Thermostat	
31		Thermostat knob	
34	9094.0665	Thermometer	
35		Heating element's warning light	
36	9162.9805	Heating element's switch	
37	9993.4039	Chamber light switch	
38	9094.0465	Heating element	
39	9094.0470	Refractory stone	
41		Terminal box	